


Schrodinger and the RDKit





(R)-Salbutamol aka albuterol

albuterol



Salbutamol aka albuterol

Salbutamol aka albuterol

A bit more complicated...

Use Enhanced Stereochemistry

Also called:

- Extended stereochemistry
- Relative stereochemistry
- Stereo groups

Specified in these file formats

- CXSMILES
- SDF v3000

We added support in the RDKit

AND: A mixture of diastereomers


 $C[C@H](O)c1cc([C@@H](O)CNC(C)(C)C)ccc1O \ | \&1:1,6|$

Or - a distinct but unknown stereoisomer

C[C@H](O)c1cc([C@@H](O)CNC(C)(C)C)ccc1O |**o1:1,6**|

ABSOLUTE: Exactly what it says in the structure

C[C@H](O)c1cc([C@@H](O)CNC(C)(C)C)ccc1O |a:1,6|



CXSMILES - Read and Write

```
In [1]: from rdkit import Chem
        import dan_rendering
In [2]: m = Chem.MolFromSmiles('C[C@H](F)C[C@@H](Br)C &1:1,4|')
Out[2]:
In [3]: Chem.MolToCXSmiles(m)
Out[3]: 'C[C@H](F)C[C@H](C)Br |&1:1,4|'
```

SD files - Read and Write


```
In [4]: print(Chem.MolToMolBlock(m))
             RDKit
                           2D
                                 0 0999 V3000
        M V30 BEGIN CTAB
        M V30 COUNTS 7 6 0 0 0
          V30 BEGIN ATOM
        M V30 1 C -2.519 -0.1968 0 0
        M V30 2 C -1.6518 0.3014 0 0
        M V30 3 F -1.6498 1.3014 0 0
        M V30 4 C -0.7868 -0.2002 0 0
        M V30 5 C 0.0802 0.298 0 0
        M V30 6 Br 0.0822 1.298 0 0
          V30 7 C 0.9452 -0.2038 0 0
        M V30 END ATOM
          V30 BEGIN BOND
        M V30 1 1 2 1 CFG=3
        M V30 2 1 2 3
        M V30 3 1 2 4
        M V30 4 1 4 5
        M V30 5 1 5 6
        M V30 6 1 5 7 CFG=1
        M V30 END BOND
          V30 BEGIN COLLECTION
        M V30 MDLV30/STERAC1 ATOMS=(2 2 5)
        M V30 END COLLECTION
          V30 END CTAB
        M END
```

Add or remove stereo groups (C++ or Python)

```
In [5]: editmol = Chem.RWMol(m)
        # Clear enhanced stereochemistry groups
        editmol.SetStereoGroups([])
        Chem.Mol(editmol)
Out[5]:
In [6]: from rdkit.Chem import rdchem
        # Add a new enhanced stereochemistry group
        group1 = rdchem.CreateStereoGroup(rdchem.StereoGroupType.STEREO AND, editmol, [1])
        editmol.SetStereoGroups([group1])
        Chem.Mol(editmol)
Out[6]:
```

Enumerate the stereoisomers (Python only)


```
In [7]: from rdkit.Chem import EnumerateStereoisomers
        # Enumerate the stereoisomers
        stereoIsomers = list(EnumerateStereoisomers.EnumerateStereoisomers(m))
        dan_rendering.renderMols(stereoIsomers)
Out[7]:
```



Match any stereoisomer with a MolBundle

Reactants with enhanced stereochemistry

Sites are preserved unless chirality is created or destroyed



Future work

- Depiction
- Canonicalization of SMILES including stereo groups
 may be complicated for "or" stereo groups
 Substructure searching with stereo groups

Conclusions

- Enhanced stereo labels allow representation of complex stereochemical relationships
- We expect that the groups will be preserved through RDKit operations
- Matching and uniquification are not seamless
- Other tools may not recognize stereo groups

Thanks

Ricardo Rodríguez-SchmidtGreg LandrumMarybeth GrimesShawn Watts

Amy Rask

dev

RDKit ddag

ddag

ddag

SCHRÖDINGER.

Transforming drug discovery and materials research